# Tel:021-88035924

**KIAN SANAT** 

Mr.lavasani



MANUAL

# INTECONT PLUS BELT SCALE CONTROLLER

PLEASE READ THIS MANUAL VERY CAREFULLY BEFORE OPERATING



# Contents

1. Introduction of Product	4
1.1Abut us	4
1.2 Overview	5
1.3 Display	6
1.4 Measure Principle	7
•	
2. Technical Data	8
2.1 Features	3
2.2 Parameters	9
2.3 Panel size1	10
3. Operation	11
3.1 Define Display	11
3.2 System Menu	
3.2.1 Display Events	
3.2.2 Stop/Start Prefeeder	
3.2.3 Service values	
3.2.4 Stop/Start Volum Mo	
3.2.5 Stop/Start Volum Sy	
3.2.6 Stop/Start Key Mode	
3.2.7 Select Batch	
3.2.8 Zero set calibration	
3.2.9 Parameters.	15
3.2.10 Calibra Functions	
3.2.11 Print FMZ	16
3.2.12 Start/Stop Clear	
3.2.13 Start/Stop Span	
3.3 Call System Menu	16
	18
	20
4. Calibration	22
4.1 Condition of Calibration	23
4.2 Check Belt Speed	23
4.3 Check Belt Cycle Pulse	23
4.4 Traeing	23
4.5 Check For Point of Zero	25
4.6 Cumulation Check	25
4.7 Check Using Material	
4.8 Linearization check	26
4.9 Set Time	27



5. Service Values	. 28
5.1 Parameter Overview	. 28
5.2 Details of Service Value	. 33
6 Communication Protocol Mod bus	4.4
6. Communication Protocol-Mod bus	
6.1 Communication Format	
6.1.1 Read Data	
6.1.2 Write Date	44
6.2 Command Operation	44
6.2.1 Read-only Command	44
6.2.2 Write-only Command	47
7. Event Messages	48
7.1 System Messages S	48
7.2 Electrical System E	48
7.3 Calibration C	49
7.4 Maximum H	49
7.5 Minimum L	50
7.6 Signal Lamps	50
8. Connection Diagram	51

# **CAUTION**

- .This is not a toy. Keep out of reach of children;
- .This controller is not an explosion proof device;
- .This controller is not a water proof device;
- .Do not open this controller, no user serviceable parts inside. Always contact supplier for service



# 1. Introduction of Product

#### 1.1 Abut us


Kian sanat INTECONT PLUS series of belt scale controller provide outstanding functionality, flexibility and reliability through innovative design with the incorporation of state-of-the-art technology all on a common modular platform.

Each instrument model is designed for specific applications and is able to be upgraded with plug in boards making it suitable for the majority of production control and monitoring functions including providing valuable data which is essential in industry today in order to satisfy up-to-the-minute process requirements.

INTECONT PLUS belt scale controller adopts 32-bit microprocessor electronics with a


110x30mm VFD display and high speed ∑-A/D conversion method with max.100 times/s conversion speed .It can make up batching scale with load cell and other mechanical parts ,applied in high speed and high precision weighing control

occasion.





### 1.2 Overview



# Application

INTECONT PLUS is mainly apply to bulk measurement in various industries such as power generation, coal industry, metallurgy, mining, harbor, chemical and building material industry.


This manual applies to controlling systems equipped with conveyor belt.

- 1. Weigh feeder
  - Control of feed rate via belt speed
- 2. Belt weigher with controlled pre feeder Control of feed rata via belt load
- 3. Belt weigher with constant load

  Control of belt load via belt speed



# 1.3 Display



## **VFD SCREEN**

VFD display with 110x30mm height . 5x7 dot matrix with 6mm character height

## LEDs:

2 green and 3 red LEDs

Green LEDs: Ready

Red LEDs: Error or limit value message

# Keyboard:

Flexible membranes with tactile touch

I 0	Start/stop		
	Preselect lower display, select functions		
Σ=0	Reset counter		
	FUNC	Enter system menu	
	DEL	Acknowledge event message, delete input	
	ESC	Abort function	
<b>←</b>	ENT	Start function, Acknowledge input	




<b>ᢒ</b>	DAT	Prepare input, e.g. of set point
0 9	Enter parameters	
- ·	Enter sign and decimal p	point

# 1.4 Measure Principle

A weigh feeder is designed to continuously weigh the material amount transported on a conveyor belt.

Weighing continuously the belt load Q and conveyor belt speed V, multiplication of the two values results in feed rate I

The sketch map as follows






# 2. Technical Data



# 2.1 Features

- -Apply to quantitative filler machine, batching belt scale, electronic weighing belt scale, belt rate monitoring, etc.
- -Language selection. English is default, second language can be Chinese
- -Self-diagnostic will display any malfunction of the load cell, speed sensor, system parts as CPU, memory, display, etc.
- -Digital electronics. Provide accurate, drift-free performance
- -Strong anti-disturbance ability





### 2.2 Parameters

Model INTECONT PLUS

Ext .Power supply AC 220V (175-285V), 30W, 50Hz

Working temperature -10-50°C Humidity ≤90%RH

Dimension 288 (W) x 190 (D) x 95 (H) mm

Weight 2.5 Kg linearity

0.01FS Accuracy
0.1% Tolerance

99999900 t

Feed rate 0.0020-99999.9 t

Division 0.001kg, 0.01kg, 0.1kg, 1kg, 0.1t, 1t...

Max.net signal input ≤30mV

Display 160\*32 VFD Screen 110x30mm

Load cell excitation DC 9V, 250mA Speed sensor DC  $\leq$ 24V, 50mA Speed pulse 0-3000Hz, 0-24V

Mod bus Interface: RS232<=1.5m RS485<=1000m

Default baud rate: 9600

(Baud rate and Communication farmat optional)

Analog Input 0-20mA, Long-distance setting the flow signal

by DCS interface

Analog Output 0-20mA, 2 Ports

1 Port for measure signal

(Flow, speed, load signal optional)

2 Port for control signal

Digital Output Touch Capacity AC 220V, 3A


Digital Input DC 24V, 4 routes Passive touch signal

route: external error acknowledge
 route: external control for stop signal
 route: external control for start signal
 route: control for speed pulse input signal


Protected class IP54





# 2.3 Panel size



# Back panel










# 3. Operation


# 3.1 Define Display



• Zo	Totalizing counter (Amount feed)	kg or t
$\bullet  Z_1 \ Z_2 \ Z_3$	Batch accumulate counter	kg or t
• Zb	Batch set point	kg or t
• Zi	Batch actual value	kg or t
• Zd	Batch residual amount  Zd=Zb-Zi	kg or t
• I	Feed rate absolute  Material amount discharged from conveyor belt per unit time	kg/h or t/h
• Ir	Feed rate/Nominal Feed rate ,feed rate relative	%
• P	Feed rate set point (nominal value) by keyboard	t/h or kg/h
• Pe	External analog signal set point by DCS interface	t/h or kg/h
• Pr	External set point for modification percentage ,relative set point	%
• Q	Belt load. Weight of material on one belt meter	kg/m
• Qr	Percentage for belt load. Belt load/nominal belt load	%
• V	Belt speed	m/s
• Xd	Deviation of feed rate	%



System Marking
Time
Kessage
Batchs



### System Marking

"." Show the system is running when it flashes

"M" Gravimetric mode. The system is in testing weight status

"V" Volumetric mode. The system is in checkout status. If "V" flashes, the system is in start-span or stop-span status

" when a batch have done in batching mode, it flashes and system will stop

" Keyboard mode start

B07 is selected as Keyboard mode absolutely ,stop/start keyboard function is invalid

"E." External set point mode. Control the System stop, start and the error message acknowledge will be due to the external digital

signal(switch signal) set point like as the external current or voltage input. If B08 value is val, press the key and Pr= will occure. Pr is external

set point for modification percentage , just a relative set point to modify the P value. Not the keyboard feed rate's function. At the same

time, the back panel 's the X6 port 6 and 7 will be closed.

"S." Serial Port mode. System run by the serial port to control. Such as flow set point, system stop, system start, error message acknowledge and some parameter modification. But all dynamic parameter can be

showed in main display with other mode when the B1 controller is running



# 3.2 System Menu

Display Events

Stop/Start Prefeeder

Service values Stop/Start

Volum Mo Stop/Start

Volum Sy Stop/Start

Key Mode Select Batch

Zero set calibra

Parameters Calibra

Calibra Functions

Print FMZ

Read parameters

**Enter Parameters** 

Load Default PAR

**Print Parameters** 

Tare

Weight

Real Weight

Belt pulse

Set Timer



### Menu function and operation

### 3.2.1 Display Events

All important scale functions are internally monitored. Errors are reported by event message. For troubleshooting details, see chapter "Event Messages".

### 3.2.2 Stop/Start Pre feeder

The "Stop/Start Pre feeder" lets you start and stop material pre feeder. The pre feeder will run with the belt electric motor when pre feeder start. And they will both stop when system stop. But if the system is in "Span mode" (The related parameter R14 is non-zero), pre feeder will stop immediately, but the belt motor need a span time to stop.

#### 3.2.3 Service values

The service table includes detailed system information. Call does not affect weighing functions. It includes hardware version, system time, belt drift parameter and so on. For troubleshooting details, see chapter "Service Values".

### 3.2.4 Stop/Start Volum Mo

Volum Mo is just for the time in which B1 controller is checking. In this mode, drive motor for conveyor belt, or material pre feeder, is controlled in proportion to set point. Belt load is of no influence. At rated conditions, feed rate corresponds to entered set point. Set point is limited to the triple nominal feed rate. Setting programs "Zero Setting", "Taring" and "Belt Circuit" are available only in Volumetric mode. And system marking "V" flashes.

### 3.2.5 Stop/Start Volum Sy

In contrast to Volumetric mode where the conveyor belt will directly run with the last speed of set point in Volumetric Synchronous Mode to save time for the

PID adjustment. Let the feed rate reach the set point quickly. If stop the Volum Sy mode, the system speed will from the 0 to the set point gradually by the PID adjustment

.



## 3.2.6 Stop/Start Key Mode

When parameter B07 selected as "Serial Port" or "Simulation" mode, we can select the "Start Key Mode" in main menu to set the feed rate and control the pre feeder's start or stop just by the keyboard. It quite suited to the fieldwork and debugging. After completing the debugging, stop Key Mode, then B1

controller can return the "Serial Port" or "Simulation" Mode to control the system system marking is ". And the

## 3.2.7 Select Batch

Call the function, the controller feed with batch by batch. Main display will add the display of Zb, Zi, Zd parameter. When completing all the batch, system will pause and "flashes. The batching value can be printed every a batch. If need

to feed next a batch, just press " " to acknowledge event than start run is ok.

### 3.2.8 Zero set calibra

The zero setting program is designed to acquire the scale's zero point error over one or multiple integer belt circuits. The acquired value is used to correct the current measuring result in normal mode. For troubleshooting details, see chapter "Zero Setting"

#### 3.2.9 Parameters

Parameters are variable characteristics or data used to match B1 controller to the application. Read, modify all the parameters of system. If having the printer option card, B1 controller can print all the parameters. Details can see in chapter "Parameters"

## 3.2.10 Calibra Functions

Calibration as such is not required. After input of rated and calibration data, scale is calibrated. Simply call:

- 1. Setting program "Belt Circuit LB" determining the basis of one belt circuit for zeroing and taring programs
- 2. Taring program TW
- 3. Zero setting program for training. Zero point error should be small after taring. Always observe the above order of sequence.

Two further checks should be effected:

- 1. Check using check weight
- 2. Check of belt speed

If something goes wrong:

our service department is always prepared to help. Maybe only some small error or maloperation is the cause of trouble. Check individual operations one by one.

Normally, the issue can be eliminated. Details can see in chapter "Calibra".



## **3.2.11 Print FMZ**

If having the printer option card, Z0, Z1, Z2, Z3 result can be printed.

## 3.2.12 Start/Stop Clear

The menu is in the "Calibration Function" of "System Menu". In "Batching Mode", B1 controller will automatically clear the belt material weight and zero check.

Normally power-off and close-down, than power-on , controller will also make a belt weight clear and zero check. When the B1 controller is in clearing the belt material weight and zero check status, can press "ESC" key to exit immediately.

However, if the system is abort suddenly when it is running or it is in "Volumetric Mode", the system will don't clear the belt material weight or take a zero check after power-on again to ensure the zero point of belt and calibration in time.

The function is suited for having pre feeder occasion. When it work, pre feeder will be shuted. And just the drive motor for conveyor belt is run.

### 3.2.13 Start/Stop Span

Start Span

When the system start with parameter  $R13\neq0$ , prefeder and drive motor for conveyor belt will both run. At this time, system is in "Volumetric Mode" and PID adjustment is invalid. The speed will be same with last time(flow speed when PID

adjustment is invariant). When it reach the number of belt circle whice amount

to parameter R13 value, PID adjustment is valid, the system marking "V" turn to "M" in main display. It means the system turn to "Gravimetric Mode". It's overcome the case effectively that belt load is zero and prefeeder is lost

control when system start.

Stop Span

When system stop with  $R14\neq0$ , pre feeder will stop immdiately. System marking "V" flashes and the material on conveyor belt will discharged completely when the number of belt circle come up to the R14 value.

# 3.3 Call System Menu

Call system menu



Call System Menu



Scroll the display into lower display field and acknowledge





Read parameters operation

ㅁ	Call system menu
	Select "Parameters" menu
-	Acknowledge
	Select the sub menu "Read parameters"
-	Acknowledge
	Scroll through parameter blocks $A,B\dots$
<b>→</b>	Acknowledge and read parameter
$\square$	Return to Previous Menu
X	Return to normal displays

# Modify Parameters Operation

	Call System menu Select the "Parameters" Menu
	Acknowledge selected
<b>\</b>	Select "Enter Parameters" menu
<b>←</b>	Acknowledge
0 9	Input the password 3.14159, acknowledge
<b>A Y</b>	Select parameter blocks
	Acknowledge
	Select parameter number
	Acknowledge
<b>£</b>	Prepare input



	Input value
	Acknowledge e or Delete Digits
	Exit and Return Previous Menu
Load Default Parameters	
	Call the system menu
	Select "Parameters" menu
-	Acknowledge
	Select sub menu "Load Default PAR"
0 9 0	Input the Password 3.95141, acknowledge selection
3.4 Basic Operation	
There is no way out.	
Who wants to B1 Controlle Operating manual.	er into service has to work himself through the
	Controller can be operated without mechanical equipment, load cells and speed is displayed, all operating functions can be performed.
1. Connect power supply and	turn on, press [ ] start key).
2. The upper two green LED indicates the controller is in	report "Ready to Operate", The turning point flashes in display window. It normal display.
3. Setting feed rate. Feed rate	can be setted by keyboard input, external analog signal input and serial port input.
	ted as "Keyboard Mode", press the Prepare input key twice continually. The et/h", setting the value. Than press to acknowledge input. If want to



If want to abort, press key please.

## b)External Analog Signal Input

when parameter B07 selected as "Analog", the feed rate is setted by the current or voltage of external analog signal. The start or stop of the controller by the external putton or PC(computer) to control

# c)Serial Port Input

When the B1 controller and PC to form a system, the feed rate can be setted by the serial port



### . 4. Clean the totalizing value

		to select the counter which need to clean.
Select the to arkinowledge clean	ing. If press key	to cancel the cleaning operation.

#### 5. Check event messages

All important scale functions are internally monitored. Errors are reported by event message. Select the "Display Events". If having errors, it will be display in event messages.

### 6. Acknowledge Messages

If having the error event, first remove cause of fault and acknowledge message. Press the DEL (cey, the B1 controller will clean the error code by the actua case. If fault is remedied after acknowledgement, message automatically effaces.

If cause has not been removed yet, the error can't be clean and error event message is still available.

### 3.5 How to Operate Your B1 Controller

- 1) The meter has been set all parameters default when leaving factory, Flow ,load ,speed signal output and Control signal of Feeder rate output, Flow setting input have already been adjusted (if you need to adjust again, please consult part 11.5 Adjust).
  - 2) When the meter install to the system, please verify the system first, please consult part six.

Please set the parameters of Block B and Block C according to the actual situation. For an example, the Actual Feed Rate (B02): 100t/h, Belt Cyc. Numb

(C02): 1, Belt Cyc. Time (the time of the belt runs one cycle, C03): 30S, Belt

Cyc Length (belt's actual length, C04): 10m, L/C Charac. Value (C05,read on the load cell label): 2mv/v, L/C Rated Cap (C06,read on the load cell label): 60kg, Eff.

Platf . Length (effective length of actual scale, C07): 1m, Lever Ratio (C08): 1, Ang le a (angle of installed scale, C09): 0, Check Weight (C10): 10kg. input the parameters above in the meter.

- 3) After checkout, please exit volumetric mode, then enter gravimetric mode, system marking show "M", press  $\[ \]$  , if there is not speed pulse signal input, circumgyrate marking will not run.
- 4) PID adjust, the defaults of R02(P\_ Component), R03(I-Component) are both 0.2, when feeding the materiel uniformly, you can minish R02 and R03, to avoid the wave motion so big.
- 5) When you don't need to adjust PID to get a steady control output current, you can stop PID adjust(R26 PID Control set to stop), then control output current will be:

I control=(P/B02)\*(R10-R09)+R09

P: flux setting B02: rating flux(Nom. Feed Rate) R09: Lower

Limit R10: Upper Limit

Press • can switch the show of P and I.

- 6) If Flow setting input is voltage, connect X4(6,8),the effection of 0V is relative to 0mA current input, and 10V is relative to 20mA, change the values of R16 and R17 to accord with the actual need.
  - 7) The marking is "E." on External set point mode, system will just run when external input X9(1,2) or



X9(3,4) is closed.

8) When X9(7,8) accumulative pulse output one pulse, the weight that pulse denotes rest with the value of B10, which can be chosen /kg, /t, /10t, /100t.			
One) Output current checkout: turn off power, press till tugening on power, when a flash cursor just display on the screen, input 4.0020, the meter will display (C.Control(0mA)) on the fist row.			
	C.Control(0mA):		
	26		
1) Control signal of Fed	eder rate output current checkout:		
of da(press can press to plus 1	D) and port 12 of X9 to current meter, adjust the value change the value of da, press again will change right about 1, press to minus 1), make sure the output current ave, the meter will display (C.Control(20mA)) on the first row.		
riess — ener to sa	C.Control(20mA):		
	969		
b. adjust the value of da, make sure the output current approach 20mA most, Press enter to save, the meter will display (C.A-A(0mA)) on the first row.			
	C.A-A(0mA):		
	28		
2) Flux output current of	checkout:		
a. Connect port 9(GND approach 0mA most, Pr	enter to save, the meter will display (C.A-A(20mA))	_	
	C.A-A(20mA):		

# INTECONT PLUS **10** SCHENCK **OPERATING MANOUAL** 978 b. adjust the value of da, make sure the output current approach 20mA most, Press enter to save, the meter will display Continue? on the first row, to exit. press Continue? Two) Input control current checkout: turn off power, press till turning on power, when a flash cursor just display on the screen, input 4.0021 to begin flux setting input checkout, the meter will display (CAL.0 EX.4mA) on the fist row. CAL.0 EX.4mA 12126 a. Between port 7 and port 8(GND) input 4mA current, wait until the value of da that display on the screen is steady, press enter to save, the meter will display (CAL.F.S EX.20mA) on the first r CAL.F.S EX.20mA 52254 b. Between port 7 and port 8(GND) input 20ma current, wait until the value of da that display on the screen is steady, press enter to save, the meter will display Continue? on the first row., press to exit.

## 4. Calibration

When the B1 controller with the scale(such as weigh feeder, belt scale) to form a weighing system, it run normally must before calibration. The weighing system's calibration and check weight, can be done by the calibration and taring function.

Continue?



e

#### 4.1 Condition of Calibration

- 1) Check Belt Speed, Belt Circuit Pulse Check, Tare Check, Zero Check, Totalizing Check must be in Volumetric Mode(System Marking V flashes). After completing the check, then return the Gravimetric Mode(System Marking M flashes). The weighing system return the normal weighing work state.
- 2) Input the parameter B block by the actual demand of the weighing system. Input the parameter C block about the mechanical part of the scale. C03 is the parameter of belt cycle time. Measure time of one belt circuit as exactly as possible and enter value into Parameter C03
- 3) Make sure conveyor belt is running(Scale ON). The feed rate is setted to MAX for keeping the belt speed is MAX

## 4.2 Check Belt Speed

1) Select the run-number of Belt Cycle Parameter C02 block

1) Call the system menu, select the Calibra Functions menu

2) Measure the time of belt cycle accurately and calculate the belt speed. Then input the value into the B05 block. To be on the safe side, conduct various measurements and calculate mean value.

 $V\!\!=\!\!L/t$   $V\!\!: Speed\ measured \qquad \qquad L\!\!: The\ length\ of\ conveyor\ belt \qquad \qquad t\!\!: The\ time\ of\ a\ belt\ cycle$ 

# 4.3 Check Belt Cycle Pulse

- 2) Input the password: 3.14159
  3) Select the Belt Pulse submenu
  4) Press the to acknowledge and start programme. Upper window displays the number of pu in the time of belt running. Lower window displays the belt speed mean value.
- 5) Press the [ to acknowledge result. The B1 will automatically to modify the parameter D06 and B04 value. If press the Abort key, the weighing system will abort and parameter D06 and B04 value not changed.

## 4.4 Tareing

- 1) Call the system menu, select the Calibra Functions menu
- 2) Input the password: 3.14159
- 3) Select the Tare sub menu



5) Press the to acknowledge result. The B1 will automatically to modify the parameter D04 value. If press the Abort key, the weighing system will abort and the calibration is invalid.
Note: The conveyor belt must be without any load or material when traeing
4.5 Check For Point of Zero
Zero setting can get the deviation of zero point from basic tare in % of normal belt load. Taring program corrects basic tare during calibration. Zero setting is designed for calibrating the current test result.
1) Call the system menu, select the Zero set calibra menu
2) Press the to acknowledge and start programie. Upper window displays the Amount of the current zero point (Like as Zo). Lower window displays the deviation of zero point from previous zero setting operation in % of nominal belt load.
3) Press the Lucial to acknowledge running result. Tare is calibrated again. Press the ESC key to cancel calibration
4.6 Cumulation Check
The cumulation check is designed for checking and testing the weighing system with simulation way. And it is used to acknowledge the precision whether meet standard or not.
1) By the mechanism of scale, put a weight on the weightbridge. Then input the known value into the parameter C09 block
2) Call the system menu, select the "Calibra Functions" menu
3) Input the password: 3.14159
4) select the "Weight" sub menu
5) Press the to acknowledge and start programme. Upper window displays the Amount of weight(unit Like as Zo). Lower window displays the percentage for weight. Known value weight/actual testing value weight by KOR.
KOR=Known value/ actual testing value weight
♦ KOR value between 0.99 ~ 1.01, scale OK, no further action required

- ♦ KOR value between 0.95 ~ 1.05, please press the Enter key and KOR value will automatically be put into the D02 parameter as a new coefficient to calibration. You also enter KOR value into Parameter D02 manually
- ♦ KOR value <0.95 or KOR value>1.05. Multi-percent deviations suggest wrong data input (e.g. belt inclination not exactly known, lever arms) and/or mechanical faults (misalignment, distorsions). Please checking the weighing system again ,then take a cumulation check.



## 4.7 Check Using Material

Checks or calibrations with check weights cannot reproduce the actual circumstances to perfection. Highly accurate weighing results can be achieved only by various measurements with material and subsequent correction.

For correction, use Parameter D02. Always

observe the following items:

- 1. Make sure the route from platform to material collecting point is clean
- 2. Ensure that material diverters, if any, do not divert any material.
- 3. If feed screws or air slides are used between platform and collecting point, feeding starts approx. 30 min. before check measurement so that normal build- ups are given.
- 4. Set dedustings to a minimum.
- 5. Ensure that hoppers or vehicles used for transport of material to a legal-for-trade weigher are cleaned and weighed before every filling operation (tare).

### Example:

Old value of Parameter D 02 = 1. Within 15 min. a material amount of W1 = 4.9 t is fed. Difference in counter reading W2 read on B1 Controller is 5.0 t. Ener computed value into Parameter D 02. D02 (new value)=D02 (old value)\* (W2/W1) W1:

Measureing weight result by B1 controller

W2: The known value of materail

### 4.8 Linearization check

Normally belt load needs not be linearized. Linearization makes good sense only with strong belt load variations and simple mechanical weighing systems.

Calibration Using Check Weights:

- 1. Apply check weight Q1, start scale and call zero setting program.
- 2. Note result of zero setting program (lower display) and enter into Parameter Lin-I1 later. Abort program; do not overwrite result.
- 3. Enter into Parameter Lin-S1.

$$q1 = \frac{Q1}{L} \bullet \frac{100\%}{q0}$$

Q1 = Check weight

in kg

L = Eff. platform length q0 = Nominal belt load

in m in kg/m

(Parameter C 06) (Parameter D01)

4. Repeat steps 1...3 for residual linearization points gradually increasing check weight. Linearization must from the first point to start. If having points don't need to linearized, it should be setted as bigger percentage compare with previous point with 100% normally



Calibration Using Check With Material:

- 1. Perform check with material using belt load q1.
- 2. Read off mean value of belt load q1 (a) from B1 controller. Enter value into Lin-I1.
- 3. Enter into Parameter Lin-S1.

$$Lin-S|=ql(a)\frac{Ms}{Ma}$$

 $Ms = Material \ amount \ fed \ in \ kg$   $Ma = Material \ amount \ read \ off \ from \ B1 \ in \ kg$ 

4. Repeat steps 1...3 for residual linearization points gradually increasing check weight. Otherwise error message S6 will occure.

# 4.9 Set Time

Unlike the other programs, date and time can be changed in Start and Stop states of scale and be read off under SERVICE VALUES.

e.g. Date 2008/02/18 Time: 09:20:30 Input: Time 92030 Date: 80218



# 5. Service Values

The Service table includes detailed system information. Call does not affect weighing functions.

The parameters are divided into several combinations in capital letters. After the letter, it is the parameter's serial number. And parameter is divided into two kinds, Option and Input.

## **5.1 Parameter Overview**

BLOCK A	Dialog Behaviour	Range	Default
A01	Language Unit	Chin/English	English
A02	Measure Units	SIS/CIA	SIS
BLOCK B	Rated Data	Range	Default
B01	Feed Rate Unit	Kg/h, t/h	Kg/h
B02	Actual Feed Rate	0.0020t/h-99999.9t/h	10.0 t/h
B03	Tacho Active	Yes/No	Yes
B04	Vs Character. Val	10.00 I/m ~ 100,000 I/m	10000.0 I/m
B05	Rated Speed	$0.0100 \text{ m/s} \sim 10.000 \text{ m/s}$	0.1000m/s
B06	VFD Brightness	40%, 60%, 100%	40%
B07	P-Source	Vol. Com. Ext	Vol
B08	Prel Ext. Active	YES, NO	NO
B09	WZ Active	YES, NO	Yes
B10	Z0 Unit	Kg, t, 10t, 100t	t
B11	Z0 Pulse dur	50ms-1000ms	50ms
B12	Z1 Unit	Kg, t, 10t, 100t	t
B13	Z1 Timer	0-240000	80000
B14	Z2 Unit	Kg, t, 10t, 100t	t
B15	Z2 Timer	0-240000	160000
B16	Z3 Unit	Kg, t, 10t, 100t	t
B17	Z3 Timer	0-240000	240000
B18	Timer Error	W1, W2, Ign, Alar	W2

BLOCK C	Enter Parameters	Range	Default
C01	Mains frequency	50Hz/60Hz	50Hz
C02	Belt Cyc. Numb	1-100(integer)	1
C03	Belt Cyc. Time	10-9999.0 s	30s
C04	Belt Cyc.Length		30.000m
C05	L/C Charac. Value	0.5~9.9999mV/V	2mv/V
C06	L/C Rated Cap	0.5~20000.0Kg	60.00Kg
C07	Eff. Platf .Length	0.1000~50.00m	0.5m
C08	Lever Ratio	0.0100~2.0000	1.0000
C09	Angle a	0.0~15.00degr	0.0
C10	Check Weight	1.000~22000.0	10.0 Kg



BLOCK D	Cal.Result	Range	Default	
D01	Nom. Belt Load	D01=B02/B05×3600 B02:t/h B05:n	m/s,D01:kg/m	27.78Kg/m
D02	Span Correction	0.5000~2.000	1.000	
D03	Total Tare	No input possible		
D04	Basic Tare N	No input possible		
D05	Tare Correction	No input possible		
D06	Belt Cyc.velum	No input possible		

BLOCK E	Analog Output	Range	Default	
E01	Output Select	I, Q, V	I	_
E02	Output MIN	0-20 mA	4 mA	
E03	Output MAX	0-20 mA	20 mA	

BLOCK F	Limit Values	Range	Default
F01	Limit Value MIN	Imin, Qmin, Vmin	Imin
F02	Limit Value MAX	Imax, Qmax, Vmax	Imax
F03	Value for I MIN	-10%~20%I	5%I
F04	Event Clas.I MIN	W1 W2 Ign A	W2
F05	Value for I.MAX	100%~200%I A	120%I
F06	Event Clas.I MAX	W1 W2 Ign A	W2
F07	Value for Q MIN	-10%~200%Q A	5%Q
F08	Event Clas.Q MIN	W1 W2 Ign A	W2
F09	Value for Q MAX	100%~200%Q A	120% Q
F10	Event Clas.Q MIN	W1 W2 Ign	W2
F11	Value for V MIN	-10~20.0% V	5%V
F12	Event Clas.V MIN	W1 W2 Ign	W2
F13	Value for V MAX	-10%~200%V	120% V
F14	Event Clas.V MAX	W1 W2 Ign	W2

BLOCK G	Filter Setting	Range	Default	
G01	I Display delay	0.0~60.0s	3.0s	
G02	I Analog Output	0.0~60.0s	3.0s	
G03	I Interface	0.0~60.0s	3.0s	
G04	Q Display	0.0~60.0s	3.0s	
G05	V Display	0.0~60.0s	3.0s	
G06	L/C Filter	0.0~60.0s	3.0s	
G07	Belt Afterfl.Tim	0.0~60.0s	3.0s	



BLOCK K K01	Inside Run Maintenance Elec	Range A 1~10000h A	Default 3000h
K02	Event Maint El	W1 W2 Ign	W2
K03	Maint Run>min	1~10000h	3000h
K04	EvMint.run	W1 W2 Ign	W2
BLOCK L	Transmit	Range	Default
L01	Protocal type	Mbus; Fbus; Dnet; JY50	Mbus
L02	Host Timeout	0~600s	10.0s
L03	Comm.Error Host	W1 W2 Ign A	W1
L04	Address	1~127	1
L05	Resolution	1~32767	4096
L06	Word Sequence	InLn; IyLn; InLy; IyLy	InLn
L07	Physics	R232; R485; R422	R485
L08	Baud Rate	4800; 9600; 19K2; 38K2	9600
L09	Format Data	8N1; 8N2; 8O1; 8E1	8N1
BLOCK Q	Event	Range	Default
Q01	Power Failure	W1,W2,Ign,Alar	W2
Q02	Memory Error	No input	W2
Q03	Tacho Input 1	W1,W2,Ign,Alar	W2
Q04	NO USE	W1,W2,Ign,Alar	W2
Q05	Namur Error GAI	W1,W2,Ign,Alar	W2
Q06	NO USE	W1,W2,Ign,Alar	A
Q07	Namur Er.IMP/Blt	W1,W2,Ign,Alar	W2
Q08	L/C Input	W1,W2,Ign,Alar	W1
Q09	NO Release	W1,W2,Ign,Alar	W1
Q10	L/C Input>MAX		
Q11	L/C Input>MIN		
Q12	Password active		
	No input		
Q13	1		
Q13	1		

BLOCK R	Control	Range	Default	
R01	Controller Type	Sta, Univers	Sta	



R02 R03	P-Component I-Component	0.000~1000.00000mA/% 0.01~600.2	0.mA/%0200 1.0s
R04	Contr.Dev.Filter	0.0~600.0s	3.0s
R05	Contr.Dev.Time	0.0~600.0s	20.0s
R06	Max.Contr.Dev	0.0~100%	5.0%
R07	Contr.Deviation	W1,W2,Ign,Alar	W1
R08	Controller Ird	W1,W2,Ign,Alar	W1
R09	Lower Limit	0~20mA	4mA
R10	Upper Limit	0~20mA	20mA
R11	Conter.Magn.Elev	0~20mA	20mA
R12	Position at Stop	0, R09	R09
R13	Start-up	0.00~2.00Uml	0.00Uml
R14	Clearamce	0.00~2.00Uml	0.00Uml
R15	NO USE	0~20.00mA	20.00mA
R16	Set point Range		
R17	Zero Set point	0~20.00mA	4mA
R18	Store	ON YES YES(A)	ON
R19	Volumeteric Mod	Qcst; Ycst	Qcst
R20	Bypass	0~20.00mA	0.00mA
R21	Set point Filt.T1	0~6000s	0.0s
R22	Set point Filt.T2	0~6000s	0.0s
R23	Set/Act Compar	W/X; X/W	W/X
R24	Set/Act Sources	I, Q	I
R25	Adaption 1	NO; V; 1/Q; 1/W	NO
R26	Adaption 2	NO; W	NO

	BLOCK P	Linear ization	Range	Default	
Ī	P01	Lin.start/stop	ON OFF	ON	
	P02	Lin-S1	0.01~1000.00% Q	20%Q	
	P03	Lin-II	0.01~1000.00%Q	20%Q	
	P04	Lin-S2	0.01~1000.00% Q	40%Q	
	P05	Lin-I2	0.01~1000.00%Q	40% Q	
	P06	Lin-S3	0.01~1000.00% Q	60% Q	
	P07	Lin-I3	0.01~1000.00%Q	60% Q	
	P08	Lin-S4	0.01~1000.00% Q	80% Q	
	P09	Lin-I4	0.01~1000.00%Q	80% Q	
	P10	Lin-S5	0.01~1000.00% Q	100% Q	
	P11	Lin-I5	0.01~1000.00% Q	100%Q	
	P12	LIN. Error	W1,W2,Ign,Alar	W2	



BLOCK H	Additional Devic	Range	Default
H01	ZDO Active	Open/Close	Open
H02	ZDO Limit	0.0~10.0% Qe	1.0% Qe
H03	<b>AUTO Zero Active</b>	open/close	open
H04	Mean Limit Value	0.0~10.0% Qe	1.0%Qe
H05	Zeroing Limit	0.0~100.0% Qe	5.0% Qe

#### Note

- 1. Verion number: INTECONT PLUS
- 2. Equipment number: F-Nr.=G xxxx (Valid when the system authorized)
- 3. Option Card: V05
- 4. Date and time: xx-xx-xx xx:xx e.g.: 08-06-28 10:18
  5. Relay out state: DA=01110010 1:on 0: off
  6. Relay in state: DE=xxx 1:on 0: off
  7. Power run time-EL=xxxh (to monitor the parameter K01)
- 8. Last run time-ED=xx h, ED>0
- 9. Belt run time-ED=xxx h (to monitor the parameter K03)
- 10. Input frequency of tachometer-Tacho input: Tacho1: xxx Hz
- 11. Percentage for belt load. Belt load/nominal belt load(L/C&Rating percent) aw=xx.xxx%
- 12. Max belt load-QMAX=xxx
- 13. Min load section-TQ<Min=xx.x mA
- 14. Percentage for last tare. Last tare/nominal load. (Last tare rating per)T1=xx.x%
- 15. Simulate out current A-A=xx.xxx mA
- 16. Output current for control(Control sim.out cr) Y\_out=xx.xxxmA
- 17. External input current for setting(Set val.sim.inp.cur) Set\_in=xx.xxx mA
- 18. (Control meter values)SIDE=xx.xxx mA
- 19. System.coefficient(Sys.coefficient)x.xxxxxxx
- 20. A/D value=xxxxxxx.x



# 5.2 Details of Service Value

# **Block A: Dialog Behaviour**

A01-Language

Selection holds for all displays, event messages and parameters.

A02-Units

Lets you change over displays and parameter inputs from SI units to American units.

## **Block B: Rated Data**

### **B01 Feed Rate Units**

Range: - - - - - t/h

- - - - - t/h

- - - - t/h

- - - - - t/h

- - - - - - t/h

- - - - - Kg /h

Determine feed rate display format for sertpoint and actual feed rate.

#### **B02** Nominal Feed Rate

Range: 0.0020...99999.9 t/h Default: 10.0000 t/h

Reference for limit values and service display.

## **B03** Tacho Active

Range: YES Default: YES

NO

Select NO to deselect speed measurement.

## **B04** Charact. Val. vs

Range: 1.00...1000 000 I/m Default: 10 000.0 I/m

Number of speed transducer pulses per belt meter.

### **B05** Nominal Speed

Range: 0.0100...10.000 m/s Default: 0.1000 m/s



Reference value for limit values.

Entry the value of parameter table.

### **B07 P-Source**

Range: Vol (keyboard) Default: Vol

Com(analog input)

Ext(serial interface)

Input feed rate setpoint by using keyboard or analog input or serial interface.

### **B08** Prel Ext. Active

Range: NO Default: NO

YES

Evaluate external setpoint in percent via keyboard.

Parameter is active only if B07 is set to ANALOG or SER.

### **B09 WZ Active**

Range: YES Default: YES

NO

Select NO to deselect belt load measurement.

Internally acts the belt load computed from nominal values.

## **B10-Z0** Unit

Total batching values and pulse weighting for external counter.

### B11-Z0 Pulse dur.

Length of external counter output pulse

#### B12-Z1 Unit



#### B13-Z1 Timer

The time of a batch for counter 1

#### **B18-Timer Error**

If a batch having a error, it will be reported by warning, ignore and alarming

## **Block C: Calibrating Data**

## **C01 Mains Frequency**

Range: 50 Hz Default: 50 Hz

60 Hz

To optimize interference suppression of mains frequency, amplifier measuring cycle is matched to mains frequency.

Do not change parameter while weigher is running.

#### C02-Belt Cyc. Numb

Determines run time of setting programs (Zero Setting, Taring, Weight Check, etc.).

### C03-Belt Cyc. Time

Determines measuring time of calibration program "Imp/Belt". Normally, the time of one belt circuit is selected.

### C04-Belt Cyc.Length

Load cell characteristic value(transmission factor)

### C05-L/C Charac. Value

Load cell characteristic value(transmission factor)

## C06-L/C Rated Cap

Total of load cells rated capacities. Pivots count load cells.

### C07-Eff. Platf. Length

Effective length of weighing platform

### **C08-Lever Ratio**

Angle of longitudinal scale axis if load cell is mounted vertically to belt.

### C09-Ang le a

Angle of longitudinal scale axis if load cell is mounted vertically to belt.

### C10-Check Weight

Material load on platform simulated through check weight.



### **Block D: Calibrat. Results**

#### D01-Nom. Belt Load

Computed from nominal values. Reference for limit values and zero setting program No entry possible. Default: 27.78 Kg/m
Computed from characteristic data B02 and B05.

#### **D02-Span Correction**

Range: 0.5000...2.0000 Default: 1.000

Use range correction of measuring system by check with material.

$$D02 = rac{ActualValue}{MeanValue}$$

#### **D03-Total Tare**

Total tare = basic tare + tare correction

#### **D04-Bassic Tare N**

Result of taring program

### **D05-Tare Correction**

Result of zero setting program Every taring operation set Parameter D 05 to 0.

## D06-Belt Cyc.velum

Result of basic calibration program "Imp/Belt". Determines run times of setting programs. Divided by Parameter B 04 (Characteristic Value vs) belt length in m results.

## **Block E: Analog Output**

# **E01-Output Select**

Range: I (feed rate) Q
(belt load)
V (belt speed) Xd
(deviation)
Y (control magnitude) P
(setpoint)

#### Default: I

One of these values can be output in analog fashion Output current for values I, Q, P and V of 100 %.

#### Note:

- 1) Maximum output current is 20 mA.
- 2) Minimum output current corresponds to elevation.
- 3) If scale is stopped, outputs for I, P and Xd are set to the elevation value. With Q and V, measurement value is output.
- 4) With control magnitude Y, parameter is irrelevant



### **Block F: Limit Values**

If measurement values exceed their MIN/MAX limits, a corresponding event message is output (L1... L3, H1... H3). Monitoring starts 10 s after start-up.

#### **F01-Limit Value MIN**

Acknowledge the limit value MIN source of event message

#### **F02-Limit Value MAX**

Acknowledge the limit value MAX source of event message

#### F03-Value for I MIN

Reference: Nominal feed rate B 02.

#### F04-Event Clas.I MIN

Range: WARNING 2, WARNING 1, IGNORE, ALARM

Default: WARNING 1

#### **F05-Value for I MAX**

Reference: Nominal feed rate B 02.

#### F06-Event Clas.I MAX

Range: WARNING 2, WARNING 1, IGNORE, ALARM

Default: WARNING 1

#### F07-Value for O MIN

Reference: Nominal belt load D 01

### F11-Value for V MIN

Reference: Nominal speed B 05

## **Block G: Filtrate Set**

I = feed rate V = belt speed

#### **G01-I Display delay**

Feed rate display

# **G02-I Analog Output**

Feed rate analog output

## **G03-I Interface**

Serial interface of Feed rate

### **G04-Q Display**

Belt load display

### **G05-V Display**

Belt speed display



### G06-L/C Filter

Applies to all functions and displays referring to belt load

### **G07-Belt Aferfi.Tim**

The delay time of Z1,Z2,Z3 counter continue to totalization after scale stop

### Block K: Inside run

## **K01-Maintenance Elec**

Alerts you on maintenance work to be effected as a function of voltage ON-time.

### **K02-Event Maint.EL**

The total of power ON-times exceeds time K01.

If a time interval has elapsed, message S4 is output.

#### **K03-Maint.Run>min**

Alerts you on maintenance work to be effected as a function of conveyor belt run time.

### K04-Ev.Maint.run<min

The total of conveyor belt run times exceeds time K03. If a time interval has elapsed, message S3 is output.

## **Block L: Transmit**

#### L01-Protocol type

Eligible protocol variants. Every protocol requires an optional interface card to be present. "COMP" identifies the compatible protocols.

## **L02-Host Timeout**

If timeout value exceeds zero, a message from host system is expected to arrive during set time.

### L03-Comm.Error Host

If no message is received during the time set by Parameter L02, event message S9 "Data Link Host" is output.

## L04-Address

Slave address for Modbus protocol.

## L05-Resolution

Resolution of data for nominal value in Modbus protocol (integer format).

### **L06-Word Sequence**

Determines the word sequence within a data double word in the Modbus protocol.

"I" stands for IEEE-754 values (floating point values)

"L" stands for 4-byte integer values

"n" does not swap the word sequence; "y" does.

#### L07-Physics

Sets interface physics for Modbus

#### L09-Format Data

Modbus data format (data bits - parity bit - stop bits)



## **Block Q: Event**

#### **O01-Power Failure**

Scale does not start automatically regardless of event class.

### **Q02-Memory Error**

Scale inoperable

## Q03-Tacho Input 1

Input frequency exceeds 2700 Hz.

## Q05-Namur Error GA1

Short-circuit or cable breakage. Namur errors set internal speed value to 0. Frequency display (service value) is still active.

### Q07-Namur Er.IMP/Blt

Namur errors set internal speed value to 0. Frequency display (service value) is still active.

## Q08-L/C Input

- 1. Load cell not (or improperly) connected.
- 2. Analog-to-digital converter of measuring amplifier is in saturation (see Service Value wz).
- 3. Supply voltage is below 19V.

## Q09-NO Release

No RELEASE input signal

Exception:

IGNORE always releases scale

### Q10-L/C Input>MAX

Load on load cell exceeds 110 % of the total of load cell rated capacities (C 04). Full scale: approx. 115 % with CSD load cells 160% with HBM load cells

## Q11-L/C Input>MIN

Load on load cell has fallen below 3% of the total of load cell rated capacities.

### Q12-Password active

Non input value. After inputting the password, B1 display message S5, don't need input the password again in 2 minutes when repeat operation

## **Block R: Control**

## **R01-Controller Type**

Controller is designed for a speed-controlled weighfeeder. It is divided into two types: Standard and Univers

### **R02-P-Component KP Reference:**

Nominal setpoint

Exception: KP = 0 results in an I controller



## **R03-I-Component TN**

Setback time TN is the time during which the I component causes

the same control magnitude change as the P component.

Exceptions:

1.KP = 0 : I controller TN is the reciprocal of integration constant KI, i.e. big value = slow controller.

KI = 1/TN in %/(mA/s) 2. TN = 0 : P controller I component is removed

3. KP=TN= 0 : Controller output = elevation

### **R04-Contr.Dev.Filter**

Filter for display and analog output of deviation, not for monitoring.

### **R05-Contr.Dev.Time**

See Parameter R 07

### R06-Max.Contr.Dev

Ref.: Nomin: al feed rate B 02, or

Nominal belt load D 01 Details :See Parameter R 07

### **R07-Contr.Deviation**

Maximum deviation exceeded. Actual feed rate inadmissibly differs from setpoint for a period longer than specified time.

There is no single cause:

## 1. Material handling error.

Material flows irregularly or cannot be easily discharged. Controller is temporarily limited.

## 2. Electronics fault.

Check external controller and motor cables. Check feed rate controller for proper setting (current limitation, speed range).

## 3. Calibration error.

Upon initial calibration, controller was set so critically that the slightest change to system characteristics can make system unreliable.

Action: Repeat this part of commissioning.

If deviation absolute value exceeds limit R06 for time R05, event message B2 (O08) is output. At 100% setpoint, effective threshold always corresponds to

Parameter R06. For smaller setpoints, decrease threshold using Parameter

Deviation Factor.

If it is 0 : effective threshold = R06 \* setpoint/nominal value

If it is 1: efective threshold = R06

### **R08-Controller Ird**

Event message B3 "Controller Limited" is output if control magnitude reaches upper response threshold



#### **R09-Lower Limit**

Lower limit of controller control magnitude.

### **R10-Upper Limit**

Upper limit of controller control magnitude. Upon inputs < 20.00 mA, limit depends on setpoint value.

## R11-Conter.Magn.Elev

Elevation of control magnitude by a constant value. Elevation acts before control magnitude limitation. With setting R 09 = R 11, control magnitude cannot fall below elevation.

Control magnitude is output in the form of impressed current of 0...20 mA. At 500 ohmic load, 20 mA correspond to 10 V.

### **R12-Position at Stop**

In Stop state of scale, control magnitude can either be set to 0 or to lower limit R09

### R13-Start-up

Volumetric start-up cycle after start of scale. After set number of belt circuits, scale goes to Volumetric (uncontrolled) mode.

"V" flashes on display

### **R14-Clearamce**

Volumetric clearance cycle after stop of scale. Material prefeeder immediately cuts off. After set number of belt circuits, belt stops.

Clearance mode should be used only if prefeeder is controlled by the B1 Controller.

"V" flashes on display

### **R16-Setpoint Range**

Analog input value Ie for 100% setpoint (nominal value B 02). For details, see Parameter R 17.

### **R17-Zero Setpoint**

Input value Ie for 0% setpoints. Values smaller than 0 % are limited to 0 %. You can also enter a voltage setpoint (0...10V). 10V corresponds to 20mA current.

## R18-Store

The parameters below can be used only if R01 is set to UNIVERS. R01 = STANDARD resets Parameters R18-R26 to default.

Stores last controller value after scale stop. Value is used for next start.

NO: Reject YES: Store

YES-A: Store only if scale has not failed due to Alarm. Alarms in Stop state of scale do not influence

stored value.



### **R19-Volumeteric Mode**

Selects Volumetric mode

Qconst : V \* Qconst acts as actual value. Scale

operates speed-controlled. V = current belt speed

Qconst = stored value, nominal belt load, or last measurement value

Yconst: Controller cut off, only setpoint bypass R20 is active.

## **R20-Bypass**

Proportional to preset setpoint, the control magnitude is additively superimposed by a value.

Parameter indicates bypass value for nominal setpoint.

## R21-Setpoint Filt.T1

First-order filter in setpoint branch; does not act on bypass.

## R22-Setpoint Filt.T2

Same as R21, but 2nd-order filter.

### R23-Set/Act Compar

W-X : Controller receives. SET/ACT deviation. X-W : Controller receives. ACT/SET deviation

#### R24-Set/Act Sources

I : Setpoint = Feed rate in accordance with Parameter B 07

Act. val. = Feed rate measured

Q : Setpoint = Nominal belt load Qo

Act. val. = Belt load measured

"Q" does not allow any of the sources specified by B 07 to be used for setpoint input.

Upper display read "Counter Z1".

## R25-Adaption 1

Adaption on controller input.

## R26-Adaption 2

Controller type FEED:R26 not accessible; corresponds to R26 = OFF

## **Block P: Linearization**

## P01-Lin.start/stop

This function lets you linearize belt load measurement.

The 4 linearization points can be acquired through calibration with check weights or check using material.

Place points not needed, or measured, outside the measuring range or interpolate.



#### P02-Lin-S1

Reference: Nominal belt load (Parameter D01).

Linearization point 1: Actual belt load

e.g. check weight or result of material measurement

### P03-Lin-I1

Reference: Nominal belt load (Parameter D01)

Linearization point 1: Belt load measured by B1 Controller

## P04-Lin-S2

Linearization point 2: see P 02

## P05-Lin-I2

Linearization point 2: see P 03

### P06-Lin-S3

Linearization point 3: see P 02

### P07-Lin-I3

Linearization point 3: see P 03

## P08-Lin-S4

Linearization point 4: see P 02

### P09-Lin-I4

Linearization point 4: see P 03

## P10-Lin-S5

Linearization point 5: see P 02

## P11-Lin-I5

Linearization point 5: see P 03

## P12-Lin.Error

Monitoring for monotonously rising compensation takes place only if linearization is active.

- 1. Upon start of linearization
- 2. Upon change to parameter

## Block H: Additional Devic

## H01-ZD0 Active

Zero Point tracking function

### H02-ZD0 Limit

The limit value for the Zero Point Tracking. Qe: Nominal load cell



## 6. Communication Protocol-Modbus

MODBUS is a network protocol of Main-Sub format. The meter is as slaves to call by the PC or host.

## **6.1 Communication Format**

### 6.1.1 Read Data

Host (Send)

IDD	Read	Add of reg H	Add of reg L	No. of Reg H	No. of Reg L	CRC H	CRC L
XX	03	00	XX	00	XX	CRC <sub>H</sub>	CRC <sub>L</sub>

Meter (Passback)

IDD	Read	No. of bytes	Word H	 Word L	CRC H	CRC L
XX	03	XX	XX	 XX	CRCH	CRCL

## 6.1.2 Write date

Host (Send)

IDD	Write	Add of reg H	Add of reg L	No. of reg H	No. of reg L	No. of bytes	Word H	 Word L	CRC H	CRC L
XX	10	00	XX	00	XX	XX	XX	 XX	CRC <sub>h</sub>	$CRC_L$

## Meter (Passback)

IDD	Write	Add of reg H	Add of reg L	No. of reg H	No. of reg L	CRC H	CRC L
XX	10	00	XX	XX	XX	CRCh	CRCL

## Note:

If the register address of sending to meter is error or CRC check having wrong, there are no data to return of the meter.

## **6.2 Command Operation**

## **6.2.1 Read-only Command**

# **SCHENCK**

Address	Code	Byte Count	Attribute	Description
0031	0	4	Bit	The bit for Event
	Alarm_H Alarm_M Alarm-L			Message
0033	SYS_status DJ-status	2	Bit	System and relay message
0034	FMZ1_H	4	Long int	Batch accumulate Counter Z1(High bits)
0036	FMZ1_L	4	Float	Batch accumulate Counter Z1(Low bits)
0038	FMZ2_H	4	Long int	Batch accumulate Counter Z2(High bits)
0040	FMZ2_L	4	Float	Batch accumulate Counter Z2(Low bits)
0042	FMZ3_H	4	Long int	Batch accumulate Counter Z3(High bits)
0044	FMZ3_L	4	Float	Batch accumulate Counter Z3(Low bit)
0046	Zd	4	Float	Batch residual amount
0048	Zi	4	Float	Batch actual value
0050	I	4	Float	Actual feed rate
0052	Q	4	Float	Belt load
0054	V	4	Float	Belt speed

## Note

1. The accumulate value to represent by 1 long integer and 1 float. e.g.

S: Sign bit

S=0: Positive number S=1: negative number

H: Hexadecimal digits for the integer

L: Hexadecimal digits for the decimal part of 0-0.999999.

## Bit Address

В	Va	Alarm_H		Alarm_M		Alarm_L		SYS_status		DJ_status				
		Name	funct ion	co de	Name	Functi	Co	Name	Func -tio	cod	Name	Func -tion	Name	Func -tion



							Τ			Ī		T	T .	
7	0				Load cell	Normal		Feed Rate	NO					
	1				cen	Error	C1	<imin< td=""><td>YES</td><td>L1</td><td></td><td></td><td></td><td></td></imin<>	YES	L1				
6	0		Relea -se		Speed Pulse	Normal		Belt Load< Qmin	NO		Volum Metri c	Stop	Belt Motor to	Non - output
	1	External STOP Key	Non- releas	S2		Exceed (	22	<b>Z</b>	YES	L2	Mode	Start	Start Light relay	output
5	0	n He	normal		Feed Rate>	NO		Belt Speed <vmin< td=""><td>NO</td><td></td><td>Speed Test?</td><td>NO</td><td>Pre- Feede r To</td><td>Non- output</td></vmin<>	NO		Speed Test?	NO	Pre- Feede r To	Non- output
	1	System run time	spill	S3		YES	H1		YES	L3		YES	start Relay	output
	0		Norma		Belt Load	NO		Empty To Load	NO	Pre-	feede r	Stop	outpu t For	Non- Output
4	1	Meter run time	Spill	S4	>Qmax	YES	H2	cell	YES	L4		Start	Relay Error	Output
3	0		Invalid		Belt Speed	NO		Power 1	Norm		ic	Stop	Belt Motor	Non- output
	1	Input password	valid	S5	>Vmax	YES	НЗ		Erro 1		Wolumetric Synchronous	Start	Drive The relay	output
2	0	Linearization Input passw	Right		Over- Load f Load			Speed Sensor	Norm		Back? To run	Stop	Relay For alarm	Non- Output
	1	Lineari	Error	S6	cell	YES	H4		Erro 1	E2		Start		output
	0	П	Invalid		Actual N Feed	1O							Belt MAX	Non- Output
	<sup>1</sup> <sub>1</sub>	signal	Valid	S7	Rate Out of		Н5						For Relay	output
	0	Analog Input			tolera Output N For								outpu t MIN For	Non- output



(	) 1		Contr Up to Limit	YES	Н6		Relay outpu t	output
			value					

## 6.2.2 Read-Write Command

Address	Byte Count	Attribute	Description
0000	2	int	Speed mode: 1 external 0 analog
0001	4	float	Rated Feed Rate
0003	2	Unsign int	Belt Cyc. Numb
0004	4	float	Belt Cyc. Time
0006	4	float	Belt length
0008	4	float	Rang of zeropoint track
0010	2	int	Baud rate: 0: 4800, 1: 9600, 2: 19200, 3: 38400
0011	2	int	Device address IDD
0012	4	float	Feed Rate Setpoint
0014	4	float	Batch setpoint Zb
0016	4	float	P value setting (0~2)
0018	4	float	I value setting (0~2)
0020	4	Long int	Totalizing counter (High bits, setting it to 0 means to clear totalizing counter, setting it to other data is noneffective)
0022	4	float	Totalizing counter (Low bits)
0024	2	int	Feeder: 1: start, 0: stop
0025	2	int	Prefeeder: 1: start, 0: stop
0026	2	int	Volumetric Mode: 1: start, 0: stop
0027	2	int	Volumetric Synchronous Mode: 1: start 0: stop
0028	2	int	Batching Mode: 1: start 0: stop
0029	2	int	Event count: setting it to 0 means to clear
0030	2	int	Batch completed symbol: 1: batch completed, 0: clear symbol



## 7. Event Messages

## 7.1 System Messages S

### S1: Memory Error

Program and parameter memories are checked in cycles. If an error is detected, scale is normally inoperable.

#### S2: No Release

No external RELEASE signal. Scale cannot start.

### S3: Maint.STR-Meter

Total ON-times of conveyor belt(Parameter K03, K04). Total ON-times of conveyor belt and measurement exceed set limit. Perform requisite service work, if necessary. Acknowledgement of message does not influence time intervals.

### S4: Maintenance Int. Elec

the maintenance time for controlling the meter maintenance(Parameter K01, K02). The B1 controller power supply has been switched on for a set time.

Perform requisite service work, if necessary. Acknowledgement of message does not influence time intervals. Parameter: K 01, K 02

## S5: Input passward valid

Operation of controlling the B1 controller is valid

### S6: Linearization

Linearization for belt load measurement improperly set. Message is output only if linearization function is active.

Action: Check relevant parameters to see if preset curve features plateaus or turning points.

## S7: Start the clearance of conveyor belt

## 7.2 Electrical System E

## E1: Power Failure

Power failed or cut off.

It is possible that totalization has stopped during this time. Action : Acknowledge message



### E2: Namur Err Tacho (GA1 Error)

Short circuit or breakage in speed transducer cable. Scale is inoperable. Action : Check speed transducer cable. Deselect speed measurement for a short time Parameter: Q05

#### E3: Reserved

### E4: Numur Err Belt Sensor

Short circuit or breakage in belt sensor cable. (Belt sensor is available only on scales using automatic belt influence compensation BIC.)

Action: Check sensor cable

Parameter: Q07

### 7.3 Calibration C

#### C1: L/C Input

- 1. Load cell cable broken, not (or improperly) connected
- 2. Supply voltage too low

Action: Check cabling. If OK, check load cell amplifier.

## C2: Tacho Input

Speed transducer output frequency exceeds 2700 Hz, most probably due to subsequent change of belt speed (e.g. gearbox).

Action: Check speed transducer for proper dimensioning. If need be, measure pulse frequency using oscillograph.

### 7.4 Maximum H

#### H1:I>MAX

Current feed rate exceeds set limit value.

Action: Normally none, unless message H4 is additionally available or system specific limits have to be observed.

Parameters: F05

H2: Load > MAX

Current belt load exceeds set limit value. Normally, weighfeeder is designed for +33% maximum belt load variation.

This is critical only with small setpoints (minimum admissible drive speed possibly exceeded down).

Action: Normally none, unless message H4 is additionally available or system specific limits have to be observed.



Parameters: F09

#### H3: V > MAX

Current belt speed exceeds set limit value.

Action: System-specific unless C2 is additionally available. Parameters: F13

## H4: L/C Input > MAX

Scale overloaded. Errors in measurement can occur.

Action : Check material infeed (belt load excessive). Parameter :

Q10

## H5: Actual feed rate exceeds set limit value

Parameter: R06

## **H6:** Output of Control have up to limit value

Parameter: R10

### 7.5 Minimum L

### L1:I < MIN

Current feed rate has fallen below set limit value. Error in measurement possibly out of tolerance.

Action: System-specific unless L4 is additionally available. Parameters: F08

### L2: Load < MIN

Current belt load has fallen below set limit value. Normally, weighfeeder is designed for +33% minimum belt load variation.

This is critical only with small setpoints (maximum admissible drive speed possibly exceeded down).

Action : see L1 Parameters : F07

#### L3: V < MIN

Current belt speed has fallen below set limit value.

Action: Check to see if belt is running.

Parameters: F11

## L4: L/C Input < MIN or Belt Load is Empty

Scale underloaded; errors in measurement possible.

Action: Check mechanical weighing system, weighed idler alignment, and load cell cable.

Parameter: Q11



## 7.6 Signal Lamps

## Warning 1(W1)

Display permanent and underscored. Totalization continues. Once occure, clear the events must by the manual operation and having memory function.

### Warning 2(W2)

The events to be clear by the automatic operation. Non-memory function.

## Ignore(Ign)

No monitoring of events, save MIN/MAX messages and deviation via contact outputs and signal lamps.

#### Alarm(Ala)

Display flashing. And the weighing system stop. Start:

First remove cause of fault and acknowledge message.

Acknowledgement:


If cause has not been removed yet, flashing stops, underscores are deleted, but message is still available. If fault is remedied after acknowledgement, message automatically effaces.

If several events occur at the same time, the most significant event is displayed first.


Priority: Alarm, Warning 1, Warning 2, sequence of event list.

## 8. Connection Diagram


## Front panel




## Back panel



# **SCHENCK**







## X1:

TERMINAL	FUNCTIO N	INTERFACE STANDARD
1, 2	Max Signal Output: closed is valid	Passive Touch
3, 4	Min Signal Output: closed is valid	Passive Touch
5, 6	Fault-free Signal Output:switching off is valid	Passive Touch

## **X2:**

TERMINAL	FUNCTIO	INTERFACE STANDARD
1 2	Power Supply Input	AC 220V MAX200mA
3 4	Meter Power Output [ - ] Meter Power Output [ + ]	DC 24V

## X3:

TERMINAL	FUNCTIO	INTERFACE STANDARD
1, 2	Speed Pulse Input: port 1 [-]	
	Port 2 [+]	
3	24V	
4~7	Reserve	

## X4:

TERMINAL	FUNCTIO	INTERFACE STANDARD
1~5	Reserve	
6	Flow setting input[+]	[DC]0~10V (Optional)
7	Flow setting input[+]	0~20mA (Optional)
8	Flow setting input[-]	CO M



## X5:

TERMINAL	FUNCTIO	INTERFACE STANDARD
1, 2	Reserve	
3	Weighing load cell Power-bridge current [ - ]	DC 10V [ - ]
4	Weighing load cell Compensating Signal [ - ]	REF [ - ]
5	Weighing load cell Input Signal [-]	IN [ - ]
6	Weighing load cell Input Signal [+]	IN [ + ]
7	Weighing load cell Compensating Signal [+]	REF[ + ]
8	Weighing load cell power-bridge current [ + ]	DC 10V [+]

## X6:

TERMINAL	FUNCTIO	INTERFACE STANDARD
1, 2	Driving signal: closed is valid	Passive Touch
3, 4	Deviation signal output: closed is valid	Passive Touch



5, 6	Pre-feeder start to ouput:closed is valid	Passive Touch
7, 8	External instruction: closed is valid	Passive Touch
9, 10	Reserve	Passive Touch

## X7:

TERMINAL	FUNCTIO	INTERFACE STANDARD
2	TXD/Printer data output	RS232
3	RXD	RS232
5	GND	
7	Printer busy	

## X8:

TERMINAL	FUNCTIO	INTERFACE STANDARD
2	A Terminal	RS485
3	B Terninal	RS485
5	GND	

## X9:

TERMINAL	FUNCTIO	INTERFACE STANDARD
1, 2	External control signal to stop: Closed is valid	Passive touch input
3, 4	External control signal to start: closed is valid after'stop' broken	Passive touch
5, 6	Reserve	
7, 8	Accumulative pulse output	MAX 300 mA (DC24V)
9 10	Flow,load,speed signal output [ - ] Flow,load,speed signal output [ + ]	0~20 mA [ DC ]
11 12	Control signal of Feeder rate output [-] Control signal of Feeder rate output [+]	0~20 mA [ DC ]


## X10:

TERMINAL	FUNCTION	INTERFACE STANDARD
1, 2	Malfunction affirmance: closed is valid	




## Load Cell Connection

## Four-Wire Connection



Six-Wire Connection

## Load cell



## If something goes wrong:

our service department is always prepared to help. Maybe only some small error or maloperation is the cause of trouble. Check individual operations one by one. Normally, the issue can be eliminated.

## **Contact us**

0912 1549668 Lavasani 021-88035924 021-88036283 farshadlavasani@gmail.com

INTECONT PLUS	
OPERATING MANOUAL	